



User Manual | Smart Power Design

Knobs Set for the Extra Bags Smart Fortwo 450



Photo 1: The four Knobs for the Extra Bags of the Smart Fortwo 450.

All work should be performed with the utmost care to avoid any damage.

Please check that the parts listed are complete before starting the installation.

For the painting of the Front Spoiler no specific instructions have to be followed.

Parts List

4 x Knobs for the extra bags in the finish of your selection

Instructions for the Extra Bags' Knobs:

- 1. Unscrew the existing knobs.
- 2. Replace them with the Smart Power Design's Knobs.

Enjoy what you have just installed. We hope that you are not going to like it but to love it as it fits perfectly on your lovely Smart Fortwo 451.



We would like to thank you for purchasing from Smart Power Design a company specialized in Smart Tuning and Accessories. If you have any problem or questions feel free to contact us via email at: info@smart-power-design.de or sales@smart-power-design.com or via telephone at: 0049-711-217-20291.

Knobs in different finishes:









- 0, 0, 0
- 1. Aluminum Finish
- 2. Chrome Finish
- 3. Chrome Mat Finish
- 4. Nickel Mat Finish
- 5. Nickel Black Finish

5)



Company Information

Smart Power Design

Möhringer Str. 93 – Stuttgart

Zip: 70199 - Germany

Email: info@smart-power-design.de

sales@smart-power-design.de

Telephone: 0049 711 217 20291

Website: www.smart-power-design.de

Follow us:









