

SMART
POWER DESIGN



SMART
POWER
DESIGN

FENDER FLARES SMART FORTWO 451

User Manual | Smart Power Design

Fender Flares Smart Fortwo 451



Photo 1: Side view of Smart Fortwo 451 with Smart Power Design's Fender Flares (front and rear Fender Flares).

All work should be performed with the utmost care to avoid any damage.

Please check that the parts listed are complete before starting the installation.

For the painting of the Front Spoiler no specific instructions have to be followed.

Parts List

2 x Rear Fender Flares

8 x Self-tapping screws

*If you order the whole kit with both rear and front Fender Flares there going to be:

2 x Rear Fender Flares

2 x Front Fender Flares

16 x Self-tapping screws

Instructions

1. The stock Fender Flares should remain on the vehicle.
2. Each of the four Smart Power Design's Fender Flares is placed over the stock ones. Be careful, to install the Front Smart Power Design's Fender Flares to the front stock ones and the rear Fender Flares to the rear stock ones.
3. Fasten the Fender Flares from inside with four self-tapping screws on each one.
4. You are ready! Installation completed.



Photo 2: Positions of the screws, there are four on each Fender Flare



Photo 3: Positions two of the four screws



Photo 4: Fender Flare (Rear Left)



Fender Flares Scoops in other colors

Enjoy what you have just installed. We hope that you are not going to like it but to love it as it fits perfectly on your lovely Smart Fortwo 451.



We would like to thank you for purchasing from Smart Power Design a company specialized in Smart Tuning and Accessories.

If you have any problem or questions feel free to contact us via email at: info@smart-power-design.de or sales@smart-power-design.com or via telephone at: 0049-711-217-20291.



Company Information

Smart Power Design
Möhringer Str. 93 – Stuttgart
Zip: 70199 – Germany

Email: info@smart-power-design.de
sales@smart-power-design.de

Telephone: 0049 711 217 20291

Website: www.smart-power-design.de

Follow us

