

SMART
POWER DESIGN



**SMART
POWER
DESIGN**

**TAIL LIGHT TRIM KIT
SMART FORTWO 451**

User Manual | Smart Power Design

Tail Light Trim Kit Smart Fortwo 451



Photo 1: Rear view of Smart Fortwo 451 with Smart Power Design's Tail Light Trim Kit installed on it.

All work should be performed with the utmost care to avoid any damage.

Please check that the parts listed are complete before starting the installation.

For the painting of the Front Spoiler no specific instructions have to be followed.

Parts List

4 x Tail Lights' Frames
(1 for each Tail Light)

Instructions

1. Firstly, check that every Tail Lights' Frame fit to each Tail Light. Please note that you shouldn't remove the protective adhesive tape yet.
2. Secondly, you should clean the Tail Lights and the area around them from the dirt and the dust in order to achieve the perfect installation.
3. The air temperature must be more than 20°C. The car must have the same temperature as well.
4. Finally, attach the frames on the Tail Lights carefully and forcefully. For the three (3) next following days do not wash the car and don't drive in the rain.



Company Information

Smart Power Design
Möhringer Str. 93 – Stuttgart
Zip: 70199 – Germany

Email: info@smart-power-design.de
sales@smart-power-design.de

Telephone: 0049 711 217 20291

Website: www.smart-power-design.de

Follow us

