

SMART
POWER DESIGN



**SMART
POWER
DESIGN**

**HANDLE COVER FOR BOOT LID
SMART FORTWO 451**

User Manual | Smart Power Design

Handle Cover of Boot Lid Smart Fortwo 451



Photo 1: The Handle Cover of Boot Lid for Smart Fortwo 451 by Smart Power Design

1. Check that the trim strip fits accurately without removing the protective foil.
2. If it's all ok, clean the vehicle trim strip adhesion area. Please note: If the trim strip has been attached in an incorrect position, it has to be removed and new adhesive strips must be placed. These are available via replacement part channels. It must be installed at a temperature (incl. vehicle temperature) of at least +21°C.

3. Pull the protective foil from the adhesive strip, and position the central section of the chrome trim strip first. Check the position and then press the central section on; then press the right and left side of the Handle Cover.
4. Following installation, check again to ensure that the chrome trim strip is installed properly and attached correctly. Do not use a car wash for 3 days. In colder seasons, do not use a car wash for at least one week.

Enjoy what you have just installed. We hope that you are not going to like it but to love it as it fits perfectly on your lovely Smart Fortwo 451.



We would like to thank you for purchasing from Smart Power Design a company specialized in Smart Tuning and Accessories.



Company Information

Smart Power Design
Möhringer Str. 93 – Stuttgart
Zip: 70199 – Germany

Email: info@smart-power-design.de
sales@smart-power-design.de

Telephone: 0049 711 217 20291

Website: www.smart-power-design.de

Follow us

