

SMART
POWER DESIGN



SMART
POWER
DESIGN

FENDER FLARES
SMART FORTWO 453

User Manual | Smart Power Design

Fender Flares Smart Fortwo 453



Photo 1: The rear left Fender Flare and Side Skirt for Smart Fortwo 453 by Smart Power Design

Parts list

8 pieces of Fender Flares

Instructions

1. Check the parts for damages before mounting.
2. Then put on the car, without pulling off the protective plastic tape, the Fender Flares to check how they fit.
3. Clean the area of the parts from dirt and wax, in order the adhesion being good.
4. Only if the fitment is ok, then please pull out the protective plastic tape and fit the Fender Flares on the car.
5. Please assemble these parts only with a temperature of more than 20° Celsius (also the surface of the vehicle must have this temperature).
6. Then attach the parts and press them.
7. Do not wash the Smart car for a day.

Note: For a better installation and application please remove the double adhesive tape and put on the Fenders Flares some Polyerathane glue. Please attach it with paper adhesive tape. After 24 hrs, you can remove the paper adhesive tape.



Fender Flares in other colors

Enjoy what you have just installed. We hope that you are not going to like it but to love it as it fits perfectly on your lovely Smart Fortwo 453. Give us a review here: <http://bitly.com/Smart-DE-Make-a-Review>



We would like to thank you for purchasing from Smart Power Design a company specialized in Smart Tuning and Accessories.

If you have any problem or questions feel free to contact us via email at: info@smart-power-design.de or sales@smart-power-design.com or via telephone at: 0049-711-217-20291.



Company Information

Smart Power Design
Möhringer Str. 93 – Stuttgart
Zip: 70199 – Germany

Email: info@smart-power-design.de
sales@smart-power-design.de

Telephone: 0049 711 217 20291

Website: www.smart-power-design.de

Follow us

